PinSound

RocketCPU WPC89 Installation Manual

x1












x1




TOOLS




(2) OPEN BACKBOX







DISCONNECT AND REMOVE ORIGINAL CPU



If your RocketCPU is "Ready To Play"







The following steps need to be followed carefully. Any failures or consequences are at your own risk and liability. In no case does the warranty cover any damages or indirect damages caused by a careless installation or handling mistake.


Please contact a technician if you do not feel confident doing it yourself.

4 REMOVE PROCESSOR U4 (5) TRANSFER U4 TO ROCKETCPU





6) REMOVE EPROM U6 (7) TRANSFER EPROM U6 TO ROCKETCPU






(8) REMOVE ASIC U9 (9) TRANSFER ASIC U9 TO ROCKETCPU






10) INSERT BATTERY

(11) INSTALL THE BOARD IN





(12)CONNECT



Ribbon cables must be positioned according to the "RED WIRE" location




Depending on your machine, some connectors might not be used

(13) CHECK DEFAULT SETTINGS









(14) MACHINE ON

(15) CHECK STATUS LED







Have fun with your new CPU!

NEED HELP?

0

www.pinsound.org/support





SoundBoard



Rediscover your pinball machine

A new sound package means a complete new game! You'll start a fresh new journey on your pinball machine.

Extended compatibility

The very same PinSound+ board can be installed in more than 100 different pinball machines.

High quality and definition

Total freedom in music creation without any limit on sound quality.

Loud and clear

Double high efficiency class-D amplifiers and advanced PinSound technology for loud and clear sound.

Sound does matter



Motion 4

Upgrade your favorite pinball machine with a shaker!



Gameplay synchronized

Hundreds of trigger possibilities



Easy to install

No technical skills needed



3 levels of power Low/Medium/High

Get ready to shake



www.pinsound.org • worldwide shipping