# **PinSound**



## Speakers kit for PLUS & NEO SEGA STERN Whitestar (wood speaker panel)





This kit is composed of 3 items

PLUS or NEO sound board is required





#### **MOUNTING SET**

- Stereo 2.1 harness
- 8 screws
- 8 spacers
- · Cable zip ties
- Manual


### **PREPARATION**

Soldering iron Screwdriver



Hexsocket screwdriver







- Open backbox
- Access the speaker panel



REMOVE ORIGINAL SPEAKERS AND ORIGINAL WIRING




**SCREW PINSOUND SPEAKERS** 




3) REMOVE WHITESTAR AUDIO CABLE

PLUS / NEO sound board




CONNECT STEREO 2.1 WIRING
PLUS / NEO sound board


74




5) CONNECT PINSOUND SPEAKERS




6) REMOVE ORIGINAL SUBWOOFER



7) SCREW PINSOUND SUBWOOFER



(8) CONNECT SUBWOOFER



9) TURN YOUR MACHINE ON



**NEED HELP?** 

