PinSound

DATA-EAST CPU EPROM

⚠ WARNING

The following steps need to be followed carefully. Any failures or consequences are at your own risk and liability. In no case does the warranty cover any damages or indirect damages caused by a careless installation or handling mistake. Please contact a technician if you do not feel confident doing it yourself.

🪛 TOOLS ① OFF ② OPEN BACKBOX

Extractor

CPU

DMD

③ LOCATE THE EPROM(S)

DATA EAST

4	5
B	B5
C	C5
D	D5

CPU Board

C5

DATA EAST

ROM 0   ROM 1

DMD Controller Board

ROM 0 / ROM 1 / ...

DATA EAST

4 EXTRACT ORIGINAL EPROM(S)

5 INSERT NEW EPROM(S)

Notch on the right

BATTERIES

4   5

B

C

D

CPU

Depending on your game, DMD display ROM upgrade may not be required.

Notch on the top

ROM 0   ROM 1

DATA EAST

DMD

6 MACHINE ON

NEED HELP?

**Have fun with your new game code!**

www.pinsound.org/support